

## Seat Back Retraction Spring Kit [002-10439-00 & -01]


## Note


Torque wrench should be capable of 33 ft-lbs (44.7 Nm).

Components: Spring ...... 1

Special Tools: Torque wrench

Language of origin: English










*Caution Retraction spring under pressure.* 


## Step 5: Remove retraction spring.


- A) Make sure seat back is fully down by pressing on seat back and/or pressing override (P button) while pressing down button on controls. Seat back should not move if in fully down position.
- B) Remove retaining wire.
- C) Move spring off stud.
- D) Remove spring from clevis block.













## Step 13: For Procenter L/R ONLY - skip if not equipped.

- A) Install PC board mounting bracket onto screws (2).
- B) Tighten ground wire screws to ensure they are secured.
- C) Install standoffs and PC board.
- D) Connect wiring to PC Board connectors.
- E) Install cover over PC board with screws (2).

