

Install Guide

Midmark 630 HumanFORM® Procedure Chair + Midmark 631-001 Procedure Chair

Applies to Models:

630 (-010 thru -013)
630 (-020 thru -023)
631-001

Language of origin: English

To install headrest assembly...

- Loosen headrest adjustment knob.
- Insert mounting stud into headrest fixture.
- Position headrest as desired.
- Tighten headrest adjustment knob.

Optional Headrest Styles

(Note: Installation is the same)

