



WARNING

Always disconnect chair from power source before removing any covers. Failure to do so may result in personal injury.

Note

This illustration shows top components removed for clarity only.

Step 1:

- Pull outward on the top of front upper cladding and unsnap.
- Unsnap side cladding from front lower cladding and rear cladding to remove.
- Remove two screws from front lower cladding.
- Remove one screw and washer from rear cladding.

