




Warning

Always disconnect power before removing covers.
Failure to do so may result in personal injury.

Step 1: To access Power Supply.

- Disconnect power.
- Remove cover(s) as needed.





DA3609i

Step 2: Removing Power Supply.

A) Unplug wiring harnesses.

B) Use needle nose pliers to release power supply.



Step 3: Installing Power Supply.

A) Snap power supply into place.

B) Plug in wire harnesses.

C) Install cover(s) as needed.

DA3610i