

Installation Instructions

Scaler Connections for Amdent Scaler System



SCALER CONNECTIONS IN THE CONSOLE



SCALER CONNECTION IN THE J BOX

