

LIN Mounted Light Kit Installation (Elevance Chairs Only) [002-1688-00]

\triangle

Warning

Always disconnect power before removing covers. Failure to do so may result in personal injury.

Attention!


Electrical installations must be completed by a Licensed Electrician.

Components:

LIN Conn. Harness. 1 Strain Relief.......... 1 Wall Cover......... 1

Special Tools:


Language of origin: English



Track Mounted Light Disconnections


Step 2: Disconnect Power Cord.

- A) Loosen screws on terminal block.
- B) Remove power cord wires from terminal block.



Step 3: Remove Power Cord.

- A) Remove strain relief from ceiling plate.
- B) Pull power cord wires thru ceiling plate.




Step A) If I B) Cu

Step 3: LIN connection preparation.


LIN Installation (Track Mounted Lights)


- A) If necessary to run wiring use 30 foot cable provided.
- B) Cut off quick disconnects.
- C) Strip approximately 1/4 inch of insulation off both wires.




Strain Relief


- A) Feed LIN connector and power cord thru both new strain relief (provided) and ceiling plate.
- B) Install strain relief into ceiling plate.





- B) Tighten terminal block screws.
- C) Route LIN wires to base of chair as required by facility.
- D) Go to Last Page in this instructions to see LIN connection to Elevance Chair.







Step 2: Disconnect Power Cord.

- A) Loosen screws on terminal block.
- B) Remove power cord wires from terminal block.
- C) Remove cable clamp from ceiling plate.

Step 3: Remove Power Cord.

- A) Remove strain relief from ceiling plate.
- B) Pull power cord wires thru ceiling plate.






LIN Installation (Ceiling Mounted Lights)

Step 3: LIN connection preparation.

- A) If necessary to run wiring use 30 foot cable provided.
- B) Cut off quick disconnects.
- C) Strip approximately 1/4 inch of insulation off both wires.




Step 4: Install Strain Relief.

- A) Feed LIN connector and power cord thru both new strain relief (provided) and ceiling plate.
- B) Install strain relief into ceiling plate.

Step 5: Connect Wires.


- A) Insert power cord and LIN connector wires into terminal block as shown.
- B) Tighten terminal block screws.
- C) Install cable clamp to ceiling plate.
- D) Route LIN wires to base of chair as required by facility.
- E) Go to Last Page in this instructions to see LIN connection to Elevance Chair.



Track Light / Monitor Disconnections


Step 2: Disconnect Power Cord.

- A) Loosen screws on terminal block.
- B) Remove power cord wires from terminal block.




Step 3: Remove Power Cord.

- A) Remove strain relief from mounting plate.
- B) Pull power cord wires thru mounting plate.




Step 3: Install Strain Relief.

- A) Feed LIN connector and power cord thru both new strain relief (provided) and ceiling plate.
- B) Install strain relief into ceiling plate.
- C) Connect LIN wires to quick disconnects.



Step 4: Connect Wires.

- A) Insert power cord wires into terminal block as shown.
- B) Tighten terminal block screws.
- C) Route LIN wires to base of chair as required by facility.
- D) Go to Last Page in this instructions to see LIN connection to Elevance Chair.




Wall / Cabinet Light Disconnections

Step 2: Remove Hole Plug.


- A) Remove hole plug from bottom cover.
- B) It is not necessary to replace bottom cover if hole plug exists.

Note: Refer to LIN Installation steps after removing Hole Plug.




Step 3: Replace bottom cover (if necessary).

- A) Disconnect transform wires from fuse holders.
- B) Disconnect power cord wires.




Step 4: Remove Bottom Cover.

A) Remove two screws and washers (save) from bottom cover.




Step 5: Assemble NEW Bottom Cover.

- A) Remove fuse holders and power cord with strain relief.
- B) Assemble fuse holders and power cord with strain relief into new bottom cover (provided).






A) Install new bottom cover using two screws and washers into wall plate.



Step 7: Connect Wiring.

- A) Connect transform wires to fuse holders.
- B) Connect power cord wires.




TP201 Rev. A

LIN Installation (Wall / Cabinet Lights)

Step 9: Install Strain Relief.

- A) Feed LIN connector thru strain relief (provided) and bottom cover.
- B) Install strain relief into bottom cover.



Step 10: Connect Wires.

- A) Connect LIN wires to quick disconnects.
- B) Route LIN wires to base of chair as required by facility.
- C) Go to Last Page in this instructions to see LIN connection to Elevance Chair.

